

# Smart Construction Fleet Release Note

App Ver : 5.11.1

Scheduled Release: January 17th (Friday) \*Only Mobile app



### We are planning to release new features for Smart Construction Fleet.

This time, we will not release any updates to the web; only the mobile app will be updated.

#### << Minor adjustments >>

•[Mobile] Change the specification to retain the assigned workplace status upon the next login

If you want to use the updated app, please update the mobile app. If you do not update, you can continue to use the current version.


Instructions on how to set up automatic updates on iPhone are provided at the <u>end</u> for your reference. The mobile app is scheduled to be released on the store on **Friday, January 17th**.

Please note that the release timing of the mobile app on the store may vary due to the review process.



## Minor adjustments





#### [Feature Description]


When logging in with the vehicle role 'Loading Area', the vehicle can belong to the loading point.


When logging in with the vehicle role 'Unloading Area', the vehicle can belong to the unloading point.


By belonging to a loading/unloading point, the vehicle will have a designated workplace radius around it and can function as a workplace.

Operation in the Mobile App You can assign a vehicle to a desired workplace by tapping on it.

Operation in the Real-Time Viewer Click on the "Location/Material" column in the "Vehicle List" to assign a vehicle to a workplace.







#### Pre-Release Specification (Before Ver. 5.11.0)

Logging out would clear the assigned workplace status.

#### Post-Release Specification (From Ver. 5.11.1)

The assigned workplace status will no longer be cleared upon logout. The same settings will be retained and available upon the next login.





## Appendix




On iPhone, by pre-setting the following, the app will be automatically updated via mobile data when updated in the store.









- ✓ Android devices may have different settings menus depending on the manufacturer
  - 1. Open the "Settings" app
  - 2. Tap on "iTunes & App Store"
  - Turn on "App Updates"
  - 4. Turn on "Automatic Downloads"

    If this option is turned off, automatic updates will only occur when connected to Wi-Fi.
  - 5. Tap on "App Downloads"
  - 6. Choose "Always Allow"
  - 7. Setting is finished